


# Maytag MDG26CTAAG 03 - CT CONTROL PANEL



Maytag [Commercial Maytag MDG26CTAAG Dryer Parts](#) Parts Diagram 03 - CT CONTROL PANEL  
 Click on the part number to view part

| Item | Original Part Number    | Replaced By               | Status        | Part Description                             |
|------|-------------------------|---------------------------|---------------|--|
| 001  | 212950                  | <a href="#">M0227520</a>  |               | Screw-Tc No.6-32 X 13/16",<br>Preform SwiTch |
| 002  | NLA                     |                           | Not Available | SPRING LEVER, RELAY                          |
| 003  | 212949                  | <a href="#">22001866</a>  |               | Screw, Relay                                 |
| 004  | NLA                     |                           | Not Available | SPACER, ADVANCE RELAY                        |
| 005  | <a href="#">212951</a>  |                           |               | Screw, No.6-32 X 1/4 Inch                    |
| "    | <a href="#">305393</a>  |                           |               | Solenoid For Relay Assembly                  |
| 006  | 307237                  | <a href="#">W10327105</a> |               | Switch, Cycle Selection                      |
| 007  | NLA                     |                           | Not Available | PILOT LIGHT                                  |
| 008  | NLA                     |                           | Not Available | CONTROL COVER (WHT)                          |
| 009  | 212276                  | <a href="#">W10116760</a> |               | Screw  |
| 010  | 306941                  | <a href="#">W10149462</a> |               | Switch, Push-To-Start                        |
| 011  | <a href="#">Y313588</a> | <a href="#">488234</a>    |               | Screw 8-32 X 1/4                             |
| 012  | 314912                  |                           | Not Available | BRACKET, CONTROL PANEL<br>(WHT)              |
| "    | NLA                     |                           | Not Available | (ALM)  |
| 013  | <a href="#">312751</a>  |                           |               | Lockwasher, Start Switch                     |

|     |                         |                        |   |
|-----|-------------------------|------------------------|---|
| 014 | Y312706                 | <a href="#">422617</a> | Nut                                     |
| 015 | <a href="#">212277</a>  |                        | Screw, No.8 X 1/2 Inch                  |
| 016 | <a href="#">Y312702</a> |                        | Knurled Nut, Start Switch               |
| 017 | <a href="#">215564</a>  |                        | Lens, Indicator Light                   |
| 018 | <a href="#">306938</a>  |                        | Knob, Selector Switch                   |
| 019 | NLA                     | Not Available          | CONTROL PANEL                           |
| 020 | NLA                     | Not Available          | WIRE HARNESS                            |
| 021 | <a href="#">205810</a>  |                        | Wire, Ground                            |
| "   | <a href="#">211252</a>  |                        | Screw, Ground Wire                      |
| 022 | 307105                  | Not Available          | COVER, TOP ASSY. (WHT)                  |
| "   | NLA                     | Not Available          | (ALM)                                   |
| 023 | <a href="#">215003</a>  |                        | Fastener, Panel And Bracket             |
| 024 | <a href="#">211294</a>  | <a href="#">90767</a>  | Screw, 8A X 3/8 HeX Washer Head Tapping |
| "   | Y314322                 | <a href="#">211251</a> | Screw, Transformer                      |
| 025 | <a href="#">211294</a>  | <a href="#">90767</a>  | Screw, 8A X 3/8 HeX Washer Head Tapping |
| "   | NLA                     | Not Available          | RELAY BRACKET                           |
| 026 | Y303787                 | Not Available          | SWITCH FOR RELAY                        |

