


# Maytag MDG26DAAAG 02 - CONTROL CENTER



4

Maytag [Commercial Maytag MDG26DAAAG Dryer Parts](#) Parts Diagram 02 - CONTROL CENTER  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	203188		Not Available	TIMER ACCESS DOOR (WHT)
"	203188L		Not Available	ACCESS DOOR-ALMOND
"	203188M		Not Available	ACCESS DOOR-HARVEST WHEAT
002	<a href="#">208042</a>			Switch, Sensor
003	912012	<a href="#">3400409</a>		Screw
004	207940	<a href="#">22001407</a>		Case, Coin Slide
"	207940L	<a href="#">22001408</a>		(ALM)
"	NLA		Not Available	(HVST WHEAT)
005	<a href="#">Y052740</a>	<a href="#">62739</a>		Nut, Lock
006	<a href="#">910181</a>			Lockwasher, Terminal Block
007	<a href="#">213035</a>			Bolt, Locking
008	NLA		Not Available	SCREW, SENSOR SWITCH BKT
009	NLA		Not Available	BRACKET, SENSOR SWITCH
010	207912	<a href="#">208884</a>		Coin Box K

"	207912L	<a href="#">208884</a>	Coin Box K
"	NLA		Not Available (HVST WHEAT)
011	<a href="#">207948</a>		Coin Drop Assembly
012	<a href="#">206799</a>		Optic Switch Assembly
013	<a href="#">314665</a>		Screw, Switch Assembly
014	<a href="#">207947</a>		Rejector, Coin
015	NLA		Not Available SCREW, COIN DROP ASSY.
016	<a href="#">216009</a>		BUTTON, RETURN
017	216010	<a href="#">Y208306</a>	Kit- Mtg C
018	<a href="#">216011</a>		Spring, Return Button
019	<a href="#">208045</a>		Harness, Wire Sensor Switch To Circuit Brd
020	NLA		Not Available HARNESS, WIRE
021	213750	<a href="#">W10133266</a>	Cam-Lock
022	212328	<a href="#">W10139762</a>	Hex Nut, 3/4-27

