


Maytag MDG27CTABW 05 - CONTROL CENTER COMPONENTS



Maytag Commercial Maytag MDG27CTABW Dryer Parts Parts Diagram 05 - CONTROL CENTER COMPONENTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	204882		Not Available	SWITCH FOR TICKET CONTROL
"	NLA		Not Available	SCREW
002	204881			Cam Plate Assembly
"	NLA		Not Available	SCREW
003	214218			Lever, Switch
004	212452			Board, Circuit
"	NLA		Not Available	SCREW
005	214275			Roller For Cam
006	214220			Adjustment Thumb Wheel
007	NLA		Not Available	SPRING WASHER
008	202479	A3167501		Lamp Oven, Int.
009	NLA		Not Available	LAMP SOCKET W/BRACKET
010	212519	488234		Screw 8-32 X 1/4
"	NLA		Not Available	FRONT PLATE
011	212533			SHIELD FOR HEAT LAMP
"	NLA		Not Available	SCREW

012	Y201110		Not Available	CONNECTOR, WIRE (INDIC. LIGHT)
013	NLA		Not Available	SCREW
014	203140			Contact Ball Kit
015	NLA		Not Available	OVERLAY
016	Y311550		Not Available	SPADE (MINIATURE)
017	NLA		Not Available	JUMPER WIRE (BLACK)
018	NLA		Not Available	SPADE CONNECTOR
019	211737	248562		Terminal
020	NLA		Not Available	HARNES, TICKET CONTROL
021	213074			Pin Receptacle For Plug
"	NLA		Not Available	PIN, PLUG
022	202713	22001555		Fuse
023	311612		Not Available	COVER, CIRCUIT BOARD TERMINALS
"	311613	Y311711		Screw, Fuse Block
024	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	NLA		Not Available	BRACKET
025	NLA		Not Available	SHIELD
026	202477	22003292		Control As
027	NLA		Not Available	FUSE BLOCK W/FUSE
028	NLA		Not Available	TICKET RECEIVER ASSY.
029	202509			Ticket Control Assembly

