


# Maytag MDG32PC3AL 08 - DOOR SWITCH ASSEMBLY



Maytag Commercial Maytag MDG32PC3AL Dryer Parts Parts Diagram 08 - DOOR SWITCH ASSEMBLY  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
000	W10124350		Not Available	ORDER PARTS FROM AMERICAN DRYER CORP AT 508-678-9000
001	A152013	<a href="#">152013</a>		6-32 Hex N
002	A153010	<a href="#">153010</a>		6 Internal
003	A137005	<a href="#">W10146741</a>		SDS Door S
004	A154281	<a href="#">154281</a>		3 8 Stand
005	A800448	<a href="#">800448</a>		12 1 2 Ma
006	A313248		Not Available	HOUSING, MAIN DOOR SWITCH
007	A150201	<a href="#">150201</a>		10-32 X 1
008	A121405	<a href="#">121405</a>		Rubber Gro