



Maytag MDG76PCBWS 16 - BURNER ASSY



REAR VIEW OF BURNER BOX



FRONT VIEW OF BURNER BOX

Maytag [Commercial Maytag MDG76PCBWS Dryer Parts](#) Parts Diagram 16 - BURNER ASSY

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
001	A141105	W10146749		Large Gas
002	A140810	140810		Burner Ori
"	A140856	140856		Burner Ori
003	A141232	141232		DSI 1 2 Ma
004	A318700	W10146865		SM Burner
005	A150108	150108		8-32 X 1 2
006	A151001	W10146764		8-32 Pal N
007	A128927		Not Available	VALVE, GAS (REDUNDANT) (1/2" 24 VAC, NATURAL GAS)
"	A880960	W10148110		1 2 24V D
008	A809309	W10147086		60 Ignitor
009	A150300	5307527001		Switch
010	A142707	142707		1 2 X 1 1
011	A142506	142506		1 2 X 1 2
012	A142600	142600		1 2 Black
013	A142804			Pipe, 1/2 X 24"

014	A128935		Not Available	DIRECT SPARK IGNITION MODULE
"	A128937		Not Available	MODULE (DSI)
"	A815724			Assembly, Bracket
015	A152013	152013		6-32 Hex N
016	A150301	150301		8-18 X 7
017	A801711			Assembly, DSI Module Mounting
018	A143000	143000		1 2 X 3 4
019	A154004	154004		Tinnerman
020	A802799	802799		Sail Sw.bo
021	A122200	122200		Sail Switch
022	A150303	150303		4 X 3 4 P
023	A105500	W10146641		Std Sail S
024	A319202	W10146866		Sail Switch
025	A154002	154002		1 8 Push O
026	A319704	WB4X122		Medallion
027	A150001	150001		6-32 X 1 2
028	A151000	WH12X195		Switch Assembly
029	A130201		Not Available	HI-LIMIT (330 DEG.)
030	A150309	W10146761		10-16 X 1
031	A314762	314762		78-88 LP B
032	A801703			Box, Burner
"	A801704	801704		Ad-78-ML-7
"	A801705			Assembly, Burner Box
033	A881655	W10148430		Ad-78-88-M

the laundry company[®]

the laundry company[®]