


Maytag MFR18PDAVS 09 - MAIN CONTROL



Maytag Commercial Maytag MFR18PDAVS Washer Parts Parts Diagram 09 - MAIN CONTROL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	23001094			Bridge, Rectifier
002	23001096			Capacitor
"	23001357			Capacitor
003	23001099			Socket, Pc Board Socket
004	23001100	23003750		Frequency Inverter Contactor
"	23001101	23003751		Contactor Lc1 D12
"	23001547			Contactor
"	23003671			Contactor
"	23003750			Frequency Inverter Contactor
"	23003751			Contactor Lc1 D12
"	23003804			Contactor, D09 115V
"	23003805			Contactor, D12 115V
007	23001106			Relay, Thermal Overload
"	23002101	23003757		Overload Relay 5.5-8A
"	23003756			Overload Relay 4-6a
"	23003757			Overload Relay 5.5-8A

010	23001513		Switch, Water Level
"	23003748		Switch, Water Level
013	23002154		Housing, Connector
014	23001114		Rocker Switch, Prewash/No Prew
015	23001115		Terminal Block Insulation
018	23001118		Sticker, Liquid Soap
020	23002111	23001013	Lock Washer External Teeth M4
021	23002398	23001089	Screw
022	23003666	23001014	Nut M4
023	23003762		Mechanical Interlock
025	23002806		Screw
026	23002651	23001312	Mut M6
027	23002425		Locker Washer M6
032	23001465		Sticker, Electricity Warning
035	23002505		Plate, Earth
036	23001138		Bushing, Cable Passage
043	23003667		Transformer, Control Board
"	23003709		Transformer, Control Board-120V
045	23003668		Resistor
046	23003675		Washer
047	NLA	Not Available	NUT (M12)

