


Maytag MFR18PDCWS 06 - CONTROL PANEL



23-Feb-06
520 794

Maytag [Commercial Maytag MFR18PDCWS Washer Parts](#) Parts Diagram 06 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	23004302			Bracket, Control Panel Lu
002	23004117			Bracket, Control Board Lu
003	23004118			MC4 Control Board
004	W10387042			MC5 Coin Program Chip Starting With Series 22
005	23004119			Display Lens
006	23004120			Infrared Lens
007	23004303			Control Panel, Facia Mfr18 Lu
008	23003646			Buttons, Row Of 3
009	23004122			Membrane Switch
010	23004123			Membrane Switch Plate
011	23003810	W10131119		Screw, 8-18 X 5/16
012	23003811			Screw
013	23004075			Dual Coin Drop Canada
"	23004124			Coin Drop
"	23004167			Optic Switch
014	23003797			Retaining Bolt

015	23004125		Z-Bracket
016	23002438		Washer M4.3
017	23002950		Lock Washer M4
018	23003666	23001014	Nut M4
019	23003778	23002756	Lockwasher
020	23002756		Lockwasher
021	23003773	Not Available	NUT M6
022	23001145		Microswitch, Lever
023	23003653		Spacer
024	23003652		Screw, Switch
025	23003654		Washer M3.2
026	23002958		Nut M3
027	23004127		Emergency Stop Interconnect
028	23002865	23001054	Washer, Locking
029	23004061		Screw M3 X 8
030	NLA	Not Available	COVER, PLASTIC
031	23004126		Double Sided Tape
032	23002455		Nut, Rapid
033	23004513		Kit, Convert PD To Pn

