


Maytag MFR50MCATS 17 - CONTROL PANEL (MC MODELS SERIES 11)



Maytag [Commercial Maytag MFR50MCATS Washer Parts](#) Parts Diagram 17 - CONTROL PANEL (MC MODELS SERIES 11)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
001	23001039			Plate, Back-Up
002	23001495			Panel, Control
003	NLA		Not Available	PLATE, INSERT (THREE BUTTONS)
004	NLA		Not Available	INSERT PLATE
005	23001041	23002524		Plate- Ind
006	23001042			Switch, Program Selector
007	23002495			Disk, Indicator
008	23001044	23002496		Disk- Indi
009	23001046			Lamp, Indicator
010	23001047	23002525		Plexi Tra
"	23001049		Not Available	LENS, TRANSPARENT RED
"	NLA		Not Available	ALUMINIUM
011	BLANK		Not Available	COINS, STICKER
012	23001063			Meter, Coin
013	23002864			Plate, Fixation

014	23002500		Washer, Lock
015	23002865	23001054	Washer, Locking
016	23002399	23001014	Nut M4
017	23001056		Ring, Shaft Locking
018	23001057	23002499	Spring Retaining Clip
019	23001058		Tube, Distance
020	23002426	23002950	Lock Washer M4
021	23001064		Screw, Ornemental
022	NLA	Not Available	PLATE, INDEX
023	NLA	Not Available	PLATE, INDEX
024	23002325		Washer
025	23002174	23003654	Washer M3.2
026	NLA	Not Available	LABEL, PUSH BUTTON
027	23001530		Button
028	23002868		Knob, Push Button
029	23001114		Rocker Switch, Prewash/No Prew
030	23001531		Button
031	23001452		Square Plug
032	23001532		Cover, Button
033	23002334		Mc To MN Convers.

