


Maytag MFX50NNATS 01 - FRAME AND COVER ASSEMBLY



Maytag Commercial Maytag MFX50NNATS Washer Parts Parts Diagram 01 - FRAME AND COVER ASSEMBLY
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	23003994			Complete Frame
002	23001550			Sticker, Service Warning
003	23001551			Gutter, Cable
004	23001552			Rivet, Blind
005	23002423	23001361		Bolt
006	23002303			Bolt
007	23001555			Bolt
008	23001551			Gutter, Cable
009	23002400			Washer
010	23001056			Ring, Shaft Locking
011	23002223			Front Panel Assembly
012	23002225			Soap Hopper Cover Assembly
013	23002226			Cover, Rear
014	23002227			Lid, Soap Box Cover
015	23001075	23002331		Contactor, Central Stop
016	23001078	23002331		Contactor, Central Stop

017	23002473		Rubber, Protective
020	23002425		Locker Washer M6
021	23003995	Not Available	LABEL STOP
022	23003996		Bolt M6x18
023	23002653	23001203	Washer
024	23002439	23001265	Washer
025	23002475	23001264	Bolt M8x20
026	23002228		Support, Front Panel
027	23002229		Panel, Front
028	NLA	Not Available	SHEET, ANTIVIBRATION
029	23002231		Cover
030	23002424		Washer M6.4
033	NLA	Not Available	PLATE, SOAP BOX COVER
035	23002233		Holder, Rear Relay
036	23001566		Switch, Magnetic
037	23002473		Rubber, Protective
038	23001567		Sheet, Anti-Vibration
039	23001468		Sticker, Spin Direction
040	23002769		Screw
043	23003666	23001014	Nut M4
045	23001573		Washer
046	23002865	23001054	Washer, Locking
051	23003997	23002243	Plug, Universal

