


Maytag MFX50NNATS 11 - MAIN CONTROL



Maytag [Commercial Maytag MFX50NNATS Washer Parts](#) Parts Diagram 11 - MAIN CONTROL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	23004067			Mounting Plate
002	23004068			Reinforcement Plate
004	23002110			Terminal Wago
005	23002099			Cube, Earth
006	23002348	23003734		Transformer
007	23002398	23001089		Screw
009	23001102			Contactora
010	23003158			Fuse, Disconnecter
011	23003716			Nut M5
012	23002802			Disconnecter, Fuse
013	23002110			Terminal Wago
014	23001462			Holder, Fuse
016	23002918	23001508		Fuse
019	23002187			Bolt, Firing
020	23002103			Trough, Cable
021	23001609	23002721		Screw

022	23001099		Socket, Pc Board Socket
023	23002129		Washer
026	23002303		Bolt
027	23002111	23001013	Lock Washer External Teeth M4
028	23001734	23002425	Locker Washer M6
029	23002129		Washer
032	23002805		Screw
033	23003773	Not Available	NUT M6
034	23001748	23002721	Screw
035	23002424		Washer M6.4
036	23002357	23002440	Washer, Spring Lock
037	23003773	Not Available	NUT M6
038	23002398	23001089	Screw
039	23002950		Lock Washer M4
040	23003666	23001014	Nut M4
041	23002092		Bolt
042	23002086		Washer, Microswitch
043	23004069		Nut, Microswitch
044	23003712		Adjustment Weight
045	23003713		Balance Switch Holder
047	23001146		Coil
050	23003714		Bolt M5x16
052	23003713		Balance Switch Holder
053	23003715		Washer, Balance Switch
055	23002862	23001708	Washer
056	23002452	8184504	Nut
057	23002077		Switch, Out Of Balance

the laundry company[®]

the laundry company[®]