

014	216200		Face Plate Return Button
"	22001873	22004112	Coin Drop Greenwald Us.25
"	22002144		Single Faceplate
015	314665		Screw, Switch Assembly
"	33001985		Switch, Optic
016	33001992		Bracket, Coin Drop Mount.
017	Y313561		Screw---NA
"	910181		Lockwasher, Terminal Block

