


Maytag MLE24PRAYW1 03 - UPPER CABINET AND FRONT PANEL PARTS



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10184604

6

[Maytag Commercial Maytag MLE24PRAYW1 Dryer Parts](#) Parts Diagram 03 - UPPER CABINET AND FRONT PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3390663	681414		Screw, 10AB X 1/2
2	3391915	681615		Screw
3	8539892			Wire-Motor To Belt Switch
4	3400077			Screw, 10-16 X 1/2
5	W10155571			Switch, Assembly
6	697773	3395530		Screw
7	3978859	280024		Cabinet
8	W10212660			Pad, Sound Dampening
9	660658			Clamp, Motor Mounting 343481 685441
10	3387374			Spring, Idler
11	3389420			Retainer-Idler 1/4-20 X 1/16
13	W10141380	W10344192		Idler Assembly
14	8529895			Tie, Cable
16	8564010			Assembly, Switch And Actuator

17	3391846		Clip, Front Panel
19	297092		Clip
23	3979115		Bracket, Angle
24	3394331		Plate Cover
25	8564011		Bracket-Switch
27	W10139766	W10396034	Motor Assembly 60 Hz
28	W10167613		Wire, Belt Switch
29	3394341	W10299847	Pulley-Motor
30	W10131172		Belt, Drive
31	3390902		Clip, Door Hinge
32	W10135695		Bracket, Motor
33	693152		Bumper, Console
34	279731	49026	4" - 90° Elbow
35	697750	W10470674	Dryer Exhaust Kit
36	3392186	4159590	Washer
37	488729		Screw
38	8283298		Jumper, Door Switch
40	W10117347		Cotter Pin
41	3406109	3406107	Door Switch Assembly
42	W10002600		Screw, 6-20 X 1 1/4
43	3389233		Bushing
44	3387242		Seal, Front Panel
45	342055	488627	Screw
46	3388229		Retainer, Toe Panel
51	W10192882	W10242810	Panel
52	696144	279570	Latch
53	3400523	285875	Kit, Security
55	3390647	488729	Screw
56	W10169676		Harness
59	98997		Clip, Harness Following Parts Optional Are Not Supplied On This Whirlpool Model. But Are Available For Purchase.
61	697215	3406797	Toe Panel
62	3389351		Top
63	689172		Foot, Dryer
64	3405160		Belt, Drive
65	3393657		Restrainer, Belt
NI	279818	W10470674	Dryer Exhaust Kit

the laundry company[®]