

# Maytag MLG15PDCXW 04 - DOOR (UPPER)



Maytag [Commercial Maytag MLG15PDCXW Dryer Parts](#) Parts Diagram 04 - DOOR (UPPER)  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">33002015</a>			Door, Outer
"	NLA		Not Available	(ALM)
002	<a href="#">22002063</a>			Screw No.8-18AB Wafer Head
"	22002064	<a href="#">489355</a>		Screw, 8 X 1/2
"	<a href="#">33002351</a>			Screw
003	<a href="#">33002017</a>			Hinge, Door
004	22002062	<a href="#">98006631</a>		Screw
005	22002300	<a href="#">9740848</a>		Screw, Mixing Valve Mounting
"	33002018	<a href="#">33002780</a>		Door Tunnel W` Handle
"	33002019	<a href="#">33002781</a>		Door Tunne
006	<a href="#">33002020</a>			Door, Inner W/Seal
"	NLA		Not Available	(ALM)
007	<a href="#">22002038</a>			Clip, Door
008	<a href="#">33001763</a>			Plug, Inner Door
009	<a href="#">33002094</a>			Seal, Door
010	<a href="#">22002039</a>			Clip, Door

011	<a href="#">33001761</a>		Strike, Door
012	<a href="#">33001793</a>		Bracket, Strike
013	33002022	<a href="#">33002607</a>	Lens, Door
"	<a href="#">33002607</a>		Lens, Door
014	<a href="#">33002038</a>		Switch, Door
015	33001711	<a href="#">33002936</a>	Medallion-
"	33002051		Not Available
			SCREW, FRONT PANEL
"	33002130	<a href="#">33002081</a>	Panel, Front
"	33002131		Not Available
			PANEL, FRONT (ALM)
"	33002381		Not Available
			PANEL, FRONT (BSQ)
016	33001486	<a href="#">98008544</a>	Screw
017	33001791	<a href="#">306436</a>	Door Latch Kit--W
018	<a href="#">33002025</a>		Twin Speednut
019	<a href="#">33001175</a>		Cover, Hinge Hole
"	<a href="#">33001176</a>		Cover, Hinge Hole
"	33002343		Not Available
			COVER, HINGE HOLE (BSQ)
020	<a href="#">33002026</a>		Extension, Tumbler Front
021	<a href="#">33001767</a>		Seal, Shroud
022	33001855	<a href="#">33002917</a>	Screw, No.10-16

