


# Maytag MLG23MNFWW 01 - CONTROL PANEL



Maytag [Commercial Maytag MLG23MNFWW Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	314723	<a href="#">W10133501</a>		Cap, Knob
002	<a href="#">312273</a>			Nut, Control Knob
003	<a href="#">314724</a>			Knob For Timer
004	<a href="#">33001500</a>			Dial, Timer Indicator
005	<a href="#">205663</a>			Knob For Selector Switch
006	<a href="#">215564</a>			Lens, Indicator Light
007	<a href="#">215506</a>			Screw, Control Panel Overlay
008	<a href="#">33002827</a>			Facia, Comm. - MN D/D
009	<a href="#">312751</a>			Lockwasher, Start Switch
"	<a href="#">Y312702</a>			Knurled Nut, Start Switch
"	Y312706	<a href="#">422617</a>		Nut
010	<a href="#">Y313588</a>	<a href="#">488234</a>		Screw 8-32 X 1/4
011	33002798	<a href="#">Y303703</a>		Pilot Light
012	306940	<a href="#">W10149462</a>		Switch, Push-To-Start
013	<a href="#">307253</a>			Switch, Cycle Selector
014	<a href="#">Y307296</a>			Timer RPR

