


Maytag MUG15MNAWW 01 - CONTROL PANEL



Maytag Commercial Maytag MUG15MNAWW Dryer Parts Parts Diagram 01 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	33002070			Overlay, Control Panel
002	215506			Screw, Control Panel Overlay
003	33002003			Fastener Clip, Control Panel
"	33002071			Panel, Control
004	215506			Screw, Control Panel Overlay
005	33001132	33002342		Plug, Sifht Hole
006	204075		Not Available	PILOT LAMP (DG MODELS ONLY)
007	306940	W10149462		Switch, Push-To-Start
008	307253			Switch, Cycle Selector
009	Y307296			Timer RPR
010	312751			Lockwasher, Start Switch
011	Y312706	422617		Nut
012	33001977			Fastener, Control Panel
013	Y313588	488234		Screw 8-32 X 1/4
014	215564			Lens, Indicator Light
015	Y313588	488234		Screw 8-32 X 1/4

016	33001500		Dial, Timer Indicator
017	314724		Knob For Timer
018	312273		Nut, Control Knob
019	314723	W10133501	Cap, Knob
020	205663		Knob For Selector Switch
021	Y312702		Knurled Nut, Start Switch
022	33001980		Fastener, Access Panel
023	215506		Screw, Control Panel Overlay
024	33002072		Panel, Access
025	33002084		Wire Harness, Main

