


Maytag MUG2000AXW 02 - CABINET-FRONT (DRYER)



Maytag [Commercial Maytag MUG2000AXW Stacked Washer and Dryer Parts](#) Parts Diagram 02 - CABINET-FRONT (DRYER)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	33001995	33002124		Cover, Top
2	33001997			Plug, Hole
3	22001883	214354		Screw, Top Cover To Cabnt.
4	33001999			Bracket, Top Cover
"	33001998			Bracket, Top Cover
5	22001995			Screw Note: Screw, Tumbler Front And Shroud
6	33001826		Not Available	BRACKET, TERMINAL BLOCK---NA
7	22001995			Screw Note: Screw, Tumbler Front And Shroud
9	Y312209	W10001200		Screw
14	33001244			Block, Terminal
16	22001502			Fastener, U-NUt
17	33002003			Fastener Clip, Control Panel
"	33002277			Cabinet
18	33001980			Fastener, Access Panel

20	207834	8566493	Power Relay
21	213007		Xfor Cabinet See Cabinet, Back
22	912077		Locknut, Reader Harness
"	22002451	22004325	Board, Machine Control
23	22002284		Bracket
24	22002519		Bracket, Machine Control Mtg.

