


Maytag MUG2000AXW 06 - CONTROL PANEL (DRYER)



Maytag Commercial Maytag MUG2000AXW Stacked Washer and Dryer Parts Parts Diagram 06 - CONTROL PANEL (DRYER)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	22002460			Facia
2	33002132			Knob, Timer
3	22001664			Timer Knob Insert/Cap
4	22002461			Knob, Timer
5	22002514			Panel, Control
"	22002063			Screw No.8-18AB Wafer Head
6	22001215	7730P011-60		Lens, Indicator Light
7	33002072			Panel, Access
"	22002063			Screw No.8-18AB Wafer Head
"	33002004			Clip, Fastener
8	33001980			Fastener, Access Panel
9	33002109			Timer
"	61001885	489399		Screw, 8-32 X 5/16
10	33001977			Fastener, Control Panel
11	33001212			Board, Control-Moisture Sensor

"	315317	488234	Screw 8-32 X 1/4
12	22002517	489355	Screw, 8 X 1/2
"	22002515		Channel, Switch Mounting
"	315471	22003298	Retainer, Wire
13	22002516		Bracket, Washer Timer
"	61001885	489399	Screw, 8-32 X 5/16
14	Y310632	1163839	Screw
"	22002452		Timer
15	33002122		Switch, Temp
16	22002518		Bracket, Pts Switch
"	Y310632	1163839	Screw
17	33001861	33001618	Switch- PU
18	33002219	22002560	Switch, Push To Start
19	22002453		Switch, Water Temp
20	22002455		Switch, Options
21	315317	488234	Screw 8-32 X 1/4
"	33001848		Signal, End Of Cycle
22	22002281		Indicator Light
23	903115		Lock Light
24	22003014		Harness, Main Wire
"	33002227	Not Available	WIRE HARNESS, MAIN (UPR)
"	22002694		Wire Harness, Main
25	22002524		Connector
26	33002225	Not Available	MANUAL, USE & CARE
"	33002234	Not Available	MANUAL, USE & CARE (FRC)
27	33002235	Not Available	VIDEO, U & C (STACK)

the laundry company[®]

the laundry company[®]