


# Maytag XAV13PRBWW 05 - BASE



Maytag [Commercial Maytag XAV13PRBWW Washer Parts](#) Parts Diagram 05 - BASE  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	21001110	<a href="#">22004376</a>		Spring, Motor Pivot
002	21001516	<a href="#">21001950</a>		MoTor, 2SP 1/2hp 120V/60Hz Hi-Tor
003	<a href="#">22002721</a>			Shield, Motor
004	35-2099	<a href="#">35-6465</a>		Pump Assem
005	25-7833	<a href="#">21001977</a>		Screw
006	<a href="#">25-7834</a>			Washer, Motor/Base Screw
007	<a href="#">33-9946</a>			Isolator, Motor
008	<a href="#">35-3570</a>			Washer, Motor Pivot
009	21001111	<a href="#">21001783</a>		Plate And Screw Assembly
"	<a href="#">35-2065</a>			Pad, Motor Plate
010	<a href="#">21001486</a>			Foot Slide, Isolator
"	<a href="#">35-3646</a>			Isolator, Motor Plate
011	<a href="#">25-7831</a>			Spacer, Mounting
012	21001506	<a href="#">21001950</a>		MoTor, 2SP 1/2hp 120V/60Hz Hi-Tor
013	25-6068	<a href="#">285655</a>		Clamp, Hose

014	<a href="#">35-3571</a>		Slide, Motor Pivot
015	<a href="#">33-9967</a>		Washer, Motor Isolator
016	<a href="#">25-7047</a>		Washer, Flat
017	25-7325	<a href="#">Y707702</a>	Locknut
018	<a href="#">21001165</a>		Spring, Suspension
019	<a href="#">21001166</a>		Hook, Suspension Spring
020	35-2049	<a href="#">21001881</a>	Bar, Stabilizer
"	<a href="#">35-2052</a>		Pin, Stabilizer
021	<a href="#">35-2046</a>		Bracket, Stabilizer
022	NLA	Not Available	GUIDE, STABILIZER BAR
023	35-3020	<a href="#">22004469</a>	Leg And Foot Self Stabalizing
024	Y31001041	<a href="#">308685</a>	Side Trim )
025	<a href="#">22002841</a>		Base
026	<a href="#">25-7845</a>		Speednut, Motor
027	35-3584	<a href="#">21001915</a>	Hose, Tub To Pump
028	35-3507	<a href="#">25001119</a>	Foot And Pad Assembly
029	<a href="#">Y25-7951</a>		Washer, Suspension Hook
030	22002709	<a href="#">22003483</a>	Belt, Drive
031	<a href="#">25-7830</a>		Spacer
032	<a href="#">33002004</a>		Clip, Fastener

