



Whirlpool 8543000 02 - TOP, HARNESS PARTS, AND OPTIONAL PARTS

TOP AND HARNESS PARTS

For Model: 8543000
(White)



8160230

4

Whirlpool [Commercial Whirlpool 8543000 Dryer Parts](#) Parts Diagram 02 - TOP, HARNESS PARTS, AND OPTIONAL PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	349639			Handle And Lint Screen Assembly
2	8283378			Cover, Lint Screen
3	3978605	W10044470		Hinge, RH
"	3978606			Hinge, Lint Lid
4	688983	487240		Screw, For Mtg. Service Capacitor
5	3395683			Receptacle, Multi-Terminal
6	8274386	8521923		Top
7	3394427			Clip-Harness
8	297535	17258		Bumper
9	94614			Terminal
10	357213			Nut, Push-In
11	8529859		Not Available	Harness, Wiring
12	3936144			Do-It-Yourself Repair Manuals
13	237446	487596		Washer

"	279948	4392065	Kit, Dryer Repair
"	8522199		Accessory Parts
"	72017		Paint, Touch-Up
"	350930		Paint, Pressurized Spray B
"	350938		Paint, Pressurized Spray B
"	799344		Paint, Touch-Up)

