


Whirlpool CA2751XSW1 02 - TOP AND CABINET , LITERATURE AND OPTIONAL



Whirlpool Commercial Whirlpool CA2751XSW1 Washer Parts Parts Diagram 02 - TOP AND CABINET , LITERATURE AND OPTIONAL

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">358473</a>			Nut, Push-In
2	388666		Not Available	Top (White)
3	<a href="#">62750</a>			Spacer, Cabinet To Top (4)
4	687128	<a href="#">681414</a>		Screw, 10AB X 1/2
5	<a href="#">3348809</a>			Cabinet (White)
6	<a href="#">62780</a>			Clip, Top And Cabinet And Rear Panel
8	354764		Not Available	Screw & Washer, Lid Switch (2)
9	63833		Not Available	Harness, Lid Switch
10	<a href="#">359231</a>			Shield, Lid Switch
11	661517	<a href="#">279347</a>		Switch-Lid
"	388322	<a href="#">279347</a>		Switch-Lid
"	359230	<a href="#">279347</a>		Switch-Lid
"	3347287	<a href="#">279347</a>		Switch-Lid

12	357347	<a href="#">359807</a>	Switch Actuator Assembly
13	355274	<a href="#">W10119828</a>	Screw, Lid Hinge Mounting
14	<a href="#">21097</a>		Pad, Lid Hinge
15	<a href="#">54584</a>		Hinge, Lid
16	<a href="#">91770</a>		Hinge, Lid
17	<a href="#">19119</a>		Bumper, Lid Hinge
18	<a href="#">21258</a>		Bearing, Lid Hinge
19	3348403	<a href="#">W10193854W10193854</a>	Lid
20	<a href="#">358684</a>		Strike, Lid Switch
22	<a href="#">356908</a>		Bumper, Lid
24	53749	Not Available	Spring & Button, Lid ((L.H.))
25	<a href="#">54690</a>		Plug, Button
26	<a href="#">358472</a>		Stop, Push-In Top
27	<a href="#">62888</a>		Plug, Terminal (3-Way)
28	384435	<a href="#">681414</a>	Screw, 10AB X 1/2
30	<a href="#">354239</a>		Rivet
31	<a href="#">90016</a>		Clip, Pressure Switch Hose
35	<a href="#">3348810</a>		Molding, Service Panel (White)
36	<a href="#">3347679</a>		Panel, Service (White)
37	3348466	<a href="#">3349596</a>	Housing, Lock
38	3348254	Not Available	Clip, Lock
39	3348465	Not Available	Lock Screw
40	3348467	Not Available	Cam Lock
41	120377	<a href="#">358160</a>	Nut
43	3348846	Not Available	Washer
44	<a href="#">388249</a>		Stand Off (3)
45	<a href="#">302252</a>		Screw, 6-32 x 1/4 (3)
46	<a href="#">3348806</a>		Bracket
47	<a href="#">3348805</a>		Bracket
48	3347711	Not Available	Rivet
49	<a href="#">445189</a>		Nut (6)
50	<a href="#">387371</a>		Lock, Plug Also Available
	<a href="#">LIT385238</a>		Guide, Laundry
"	LIT387194	Not Available	Sheet, Installation Instructions
"	<a href="#">LIT388520</a>		Guide, Use and Care
"	<a href="#">LIT387736</a>		Label, Energy Guide
"	<a href="#">LIT385292</a>		List, Repair Parts
"	<a href="#">72017</a>		Paint, Touch-Up
"	<a href="#">72107</a>		Paint, Touch-Up
"	<a href="#">72110</a>		Paint, Touch-Up 1/2 Oz.
"	350941	Not Available	Leveler (Thinner)
"	<a href="#">350938</a>		Paint, Pressurized Spray B
"	<a href="#">350930</a>		Paint, Pressurized Spray B
"	<a href="#">350956</a>		Paint, Spray 13 Oz.
"	<a href="#">261880</a>		Golden Harvest
"	<a href="#">799344</a>		Paint, Touch-Up )
"	<a href="#">978883</a>		Almond
"	261891	Not Available	Golden Harvest (Uncut)
"	<a href="#">350572</a>		Oil
"	<a href="#">285208</a>		Lubricant
"	<a href="#">285195</a>		Sealer Sealer, Gasket