


Whirlpool CA2751XSW4 06 - AGITATOR, BASKET AND TUB



Whirlpool [Commercial Whirlpool CA2751XSW4 Washer Parts](#) Parts Diagram 06 - AGITATOR, BASKET AND TUB
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|------------------------|-------------------------|--------|------------------------------|
| 1 | 3388571 | 3355758 | | Cap, Agitator |
| 4 | 358237 | | | Screw And Washer |
| 5 | 3350151 | 285622 | | Agitator |
| 6 | 387966 | 3360611 | | Tub Ring And Gasket Assembly |
| 7 | 63222 | 3359586 | | Gasket, Tub Ring |
| 8 | 21366 | | | Nut, Spanner |
| 9 | 3349748 | 3956207 | | Basket And Balance Ring |
| 11 | 63125 | | | Tub |
| 13 | 389140 | | | Tub Block, Basket Drive |
| 14 | 383727 | | | Gasket, Centerpod |
| 15 | 386757 | 353244 | | Hose, Pressure Switch |
| 16 | 387867 | 8519815 | | Clip, Balance Ring |
| 17 | 387868 | 3956205 | | Balance Ring |