


Whirlpool CA2751XSW4 12 - GEARCASE



Whirlpool [Commercial Whirlpool CA2751XSW4 Washer Parts](#) Parts Diagram 12 - GEARCASE

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	389246	3360629		Gearcase
2	62685	285202		Cover, Gearcase
3	3347188	3349985		Seal, Gearcase Cover
4	285195			Sealer Sealer, Gasket
5	63320	285362		Gear and Pinion
6	356427			Seal, Spin Pinion
7	389387			Shaft, Agitator
8	90369		Not Available	Ring, Retaining (2)
9	62677			Retainer, Spring
10	62676			Spring, Agitator
11	63273	285509		Shaft, Agitator
12	62619			Washer, Agitator Gear
13	62580	285206		Cam-Agitator
14	62581	285206		Cam-Agitator
15	389231			Shaft, Agitator
16	62618			Washer, Cam Thrust

17	16018	285205	Bearing
18	85529	285205	Bearing
19	389229	285515	Gearcase
20	62528	285515	Gearcase
21	285352		Seal Kit, Thrust Plug
22	90864	3351614	Screw, Gearcase Cover Mounting
23	95082	285765	Ring-Retrn
24	285292	285766	Washer Kit, Thrust
25	62570	285362	Gear and Pinon
26	388253	999516	Shelf-Glas
27	62534	8546456	Rack, Connecting
28	62621		Actuator, Shift
29	388815		Washer, Intermediate 1 3976263 Miscellaneous Parts Bag 2 3976300 Washer, Inlet Hose 3 3366913 Clamp, Hose

the laundry company[®]

Howes
the laundry company[®]

Howes
the laundry company[®]