


# Whirlpool CA2751XWG1 06 - AGITATOR, BASKET AND TUB

## AGITATOR, BASKET AND TUB PARTS

For Model: CA2751XWW1



3355015

8

Whirlpool [Commercial Whirlpool CA2751XWG1 Washer Parts](#) Parts Diagram 06 - AGITATOR, BASKET AND TUB  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">3355758</a>			Cap, Agitator
2	3352284	<a href="#">285630</a>		Plug
4	<a href="#">358237</a>			Screw And Washer
5	3350151	<a href="#">285622</a>		Agitator
6	387966	<a href="#">3360611</a>		Tub Ring And Gasket Assembly
7	63222	<a href="#">3359586</a>		Gasket, Tub Ring
8	<a href="#">21366</a>			Nut, Spanner
9	3349748	<a href="#">3956207</a>		Basket And Balance Ring
11	<a href="#">63125</a>			Tub
13	<a href="#">389140</a>			Tub Block, Basket Drive
14	<a href="#">383727</a>			Gasket, Centerpod
15	386757	<a href="#">353244</a>		Hose, Pressure Switch
16	387868	<a href="#">3956205</a>		Balance Ring
17	387868	<a href="#">3956205</a>		Balance Ring