


Whirlpool CA2751XWN1 03 - CONTROL PANEL

CONTROL PANEL PARTS

For Model: CA2751XWW1



3355015

4

Whirlpool [Commercial Whirlpool CA2751XWN1 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3353946			Panel, Console
2	3352860			Bracket, Control
3	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
4	389138	3355916		Switch, Cycle Selector
5	9424101	965173		Screw, 8 X 3/8 Phlps. Round Hd.
6	3347705			End Cap
9	3352457			Lights, Indicator
10	3348109			Lens Light
11	3348110			Lens, Yellow
12	3348587			Button, Pushbutton
15	3348542	279947		Switch-WL
16	63789	285653		Endcap
17	689559			Nut, Push-In
18	355326		Not Available	Screw, End Cap To Bracket (4)

