


Whirlpool CA2751XWW1 06 - AGITATOR, BASKET AND TUB

AGITATOR, BASKET AND TUB PARTS

For Model: CA2751XWW1



Whirlpool [Commercial Whirlpool CA2751XWW1 Washer Parts](#) Parts Diagram 06 - AGITATOR, BASKET AND TUB
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3355758			Cap, Agitator
2	3352284	285630		Plug
4	358237			Screw And Washer
5	3350151	285622		Agitator
6	387966	3360611		Tub Ring And Gasket Assembly
7	63222	3359586		Gasket, Tub Ring
8	21366			Nut, Spanner
9	3349748	3956207		Basket And Balance Ring
11	63125			Tub
13	389140			Tub Block, Basket Drive
14	383727			Gasket, Centerpod
15	386757	353244		Hose, Pressure Switch
16	387868	3956205		Balance Ring
17	387868	3956205		Balance Ring