


Whirlpool CAE2792EW0 05 - AGITATOR, BASKET AND TUB



Whirlpool [Commercial Whirlpool CAE2792EW0 Washer Parts](#) Parts Diagram 05 - AGITATOR, BASKET AND TUB
Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|-------------------------|--------|------------------------------|
| 1 | 3355758 | | | Cap, Agitator |
| 2 | 3352284 | 285630 | | Plug |
| 3 | 3349610 | | | Mover, Agitator Clutch |
| 4 | 358237 | | | Screw And Washer |
| 5 | 3360279 | 3349578 | | Agitator |
| 6 | 3360611 | | | Tub Ring And Gasket Assembly |
| 7 | 3359586 | | | Gasket, Tub Ring |
| 8 | 21366 | | | Nut, Spanner |
| 9 | 3349748 | 3956207 | | Basket And Balance Ring |
| 10 | 3366877 | 80040 | | Dog-Agitator |
| 11 | 63125 | | | Tub |
| 12 | 3947410 | 285751 | | Dog-Agitator |
| 13 | 389140 | | | Tub Block, Basket Drive |
| 14 | 383727 | | | Gasket, Centerpodt |
| 15 | 3347778 | 353244 | | Hose, Pressure Switch |
| 16 | 387868 | 3956205 | | Balance Ring |

| | | | |
|----|-----------------------|---------------------------|-----------------|
| 17 | 387868 | 3956205 | Balance Ring |
| 18 | 64002 | | Seal, Agitator |
| 19 | 3351014 | 285620 | Washer |
| 20 | 387094 | 285550 | Cap |
| 21 | 3348855 | W10072840 | Fabric Softener |
| 22 | 3947411 | 3349743 | Agitator |

