


Whirlpool CAM2742TQ0 02 - CONTROL PANEL PARTS

CONTROL PANEL PARTS

For Models: CAM2742TQ0, CAM2742TQ2
(White) (White)



W10114743

4

Whirlpool [Commercial Whirlpool CAM2742TQ0 Washer Parts](#) Parts Diagram 02 - CONTROL PANEL PARTS
Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|---------------------------|--------|---|
| 1 | 8577883 | | | Panel, Console |
| 2 | 3978858 | | | Bracket, Control |
| 3 | 8578168 | | | Control, Automatic Temp. |
| 4 | 8577359 | | | Switch, Cycle Selector |
| 5 | 3390646 | W10139210 | | Screw, 8-18 X 5/16 |
| 6 | 3949740 | | | End Cap |
| 7 | 8281182 | | | Screw, 8-18 X 1 1/4 |
| 8 | 8573825 | W10351806 | | Switch-WL |
| 9 | 3352457 | | | Lights, Indicator |
| 10 | 3348109 | | | Lens Light |
| 11 | 3348110 | | | Lens, Yellow |
| 12 | 8316433 | | | Pushbutton |
| 13 | 8524802 | W10339319 | | Switch-WL |
| 14 | 3400073 | | | Screw, Ground |
| 15 | 90767 | | | Screw, 8A X 3/8 HeX Washer Head Tapping |
| 16 | 3949734 | W10096320 | | Cap, End |

| | | | |
|----|---------------------------|---------------------------|-------------------------|
| 17 | 689559 | | Nut, Push-In |
| 18 | 97787 | W10109200 | Screw, Baffle Mounting |
| 19 | W10138030 | | Harness, Console Wiring |
| 20 | 357572 | W10113937 | Clip, Grounding |

