


Whirlpool CAM2742TQ3 06 - BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS



Whirlpool [Commercial Whirlpool CAM2742TQ3 Washer Parts](#) Parts Diagram 06 - BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	388952	285792		Basketdrive
2	63292			Washer, Spin Tube Thrust
3	62697	W10080230		Ring, Spin Tube Support
4	63283	285353		Ring
5	8299642			Clutch
6	3951993			Band And Lining, Clutch
7	62646			Cap, Clutch Spring
8	8559387			Spring And Damper Assembly
9	3360630	3360629		Gearcase
10	3357334	3400516		Screw Anti-Rattle
11	62611			Plate, Motor Mount To Gearcase
12	62691			Grommet, Motor
13	3978849	285852A		Coupling
14	3387485	273556		Screw, 10-16 X 5/8

15	3946532	Shield, Motor
16	3400516	Screw Anti-Rattle
17	W10086010	Retainer, Motor
18	3362089	Shield, Tub To Motor
19	661600	Motor, Main Drive
21	8546127	Retainer, Pump
22	3363394	Pump
23	62863	3390631 Screw, 10-16 X 3/8
24	3355454	Clip, Main Drive
25	8572717	Capacitor, Motor Start
26	3949496	Clamp, Capacitor
27	8577374	Seal, Centerpost

the laundry company[®]

the laundry company[®]

the laundry company[®]