


Whirlpool CAM2761KQ0 03 - CONTROL PANEL

CONTROL PANEL PARTS

For Model: CAM2761KQ0
(White)



8524723

4

Whirlpool [Commercial Whirlpool CAM2761KQ0 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8316234			Panel, Console
2	3361029			Bracket, Control
3	3400073			Screw, Ground
4	8316440			Switch, Cycle Selector
5	3390646	W10139210		Screw, 8-18 X 5/16
6	8316516	W10096340		Cap, End
7	8281182			Screw, 8-18 X 1 1/4
8	3398893	3395559		Wire
9	3352457			Lights, Indicator
10	3348109			Lens Light
11	3348110			Lens, Yellow
12	8316433			Pushbutton
13	359702	W10491983		Tip-Tines
16	3949734	W10096320		Cap, End
17	689559			Nut, Push-In
18	97787	W10109200		Screw, Baffle Mounting

