


# Whirlpool CAM2762RQ0 05 - AGITATOR, BASKET AND TUB PARTS

## AGITATOR, BASKET AND TUB PARTS

For Model: CAM2762RQ0

(White)



8579450

8

Whirlpool [Commercial Whirlpool CAM2762RQ0 Washer Parts](#) Parts Diagram 05 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">3352483</a>			Cap, Agitator
2	8519788	<a href="#">387240</a>		Ring, Balance
3	<a href="#">3949550</a>			Washer
4	<a href="#">358237</a>			Screw And Washer
5	<a href="#">63377</a>			Agitator
6	<a href="#">8528150</a>	<a href="#">W10445870</a>		Ring-Tub
7	<a href="#">3976308</a>			Gasket, Tub Ring
8	<a href="#">21366</a>			Nut, Spanner
9	<a href="#">8526017</a>	<a href="#">W10389329</a>		Clothes Container, Assembly
10	<a href="#">63849</a>			Strain Relief, Power Cord
11	<a href="#">389140</a>			Tub Block, Basket Drive
12	<a href="#">383727</a>			Gasket, Centerpod