


# Whirlpool CAM2762TQ0 05 - AGITATOR, BASKET AND TUB PARTS

## AGITATOR, BASKET AND TUB PARTS

For Models: CAM2762TQ0, CAM2762TQ2

(White) (White)



W10114745

8

Whirlpool Commercial Whirlpool CAM2762TQ0 Washer Parts Parts Diagram 05 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">3352483</a>			Cap, Agitator
2	<a href="#">358237</a>			Screw And Washer
3	<a href="#">3949550</a>			Washer
4	<a href="#">63377</a>			Agitator
5	<a href="#">8528150</a>	<a href="#">W10445870</a>		Ring-Tub
6	<a href="#">3976308</a>			Gasket, Tub Ring
7	<a href="#">21366</a>			Nut, Spanner
8	<a href="#">387240</a>			Ring, Balance
9	<a href="#">8526017</a>	<a href="#">W10389329</a>		Clothes Container, Assembly
10	<a href="#">389140</a>			Tub Block, Basket Drive
11	W10135425	<a href="#">63849</a>		Strain Relief, Power Cord
12	<a href="#">383727</a>			Gasket, Centerpod