


Whirlpool CAM2762TQ2 05 - AGITATOR, BASKET AND TUB PARTS

AGITATOR, BASKET AND TUB PARTS

For Models: CAM2762TQ0, CAM2762TQ2

(White) (White)



W10114745

8

Whirlpool Commercial Whirlpool CAM2762TQ2 Washer Parts Parts Diagram 05 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3352483			Cap, Agitator
2	358237			Screw And Washer
3	3949550			Washer
4	63377			Agitator
5	8528150	W10445870		Ring-Tub
6	3976308			Gasket, Tub Ring
7	21366			Nut, Spanner
8	387240			Ring, Balance
9	8526017	W10389329		Clothes Container, Assembly
10	389140			Tub Block, Basket Drive
11	W10135425	63849		Strain Relief, Power Cord
12	383727			Gasket, Centerpod