


Whirlpool CAP2761EW0 05 - AGITATOR, BASKET AND TUB



Whirlpool [Commercial Whirlpool CAP2761EW0 Washer Parts](#) Parts Diagram 05 - AGITATOR, BASKET AND TUB
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3355758			Cap, Agitator
2	3352284	285630		Plug
3	3349610			Mover, Agitator Clutch
4	358237			Screw And Washer
5	3360279	3349578		Agitator
6	3360611			Tub Ring And Gasket Assembly
7	3359586			Gasket, Tub Ring
8	21366			Nut, Spanner
9	3349748	3956207		Basket And Balance Ring
10	3366877	80040		Dog-Agitator
11	63125			Tub
12	3947410	285751		Dog-Agitator
13	389140			Tub Block, Basket Drive
14	383727			Gasket, Centerpodt
15	353405	353244		Hose, Pressure Switch
16	387868	3956205		Balance Ring

17	387868	3956205	Balance Ring
18	64002		Seal, Agitator
19	3351014	285620	Washer
20	387094	285550	Cap
21	3348855	W10072840	Fabric Softener
22	3947411	3349743	Agitator
23	3949550		Washer

