


Whirlpool CAW2762KQ0 03 - CONTROL PANEL

CONTROL PANEL PARTS

For Model: CAW2762KQ0
(White)



8524728

4

Whirlpool [Commercial Whirlpool CAW2762KQ0 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8318581			Panel, Console
2	3978858			Bracket, Control
3	8524791	353244		Hose, Pressure Switch
4	3954774			Switch, Cycle Selector
5	3390646	W10139210		Screw, 8-18 X 5/16
6	3949740			End Cap
7	8281182			Screw, 8-18 X 1 1/4
8	8524802	W10339319		Switch-WL
9	3352457			Lights, Indicator
10	3348109			Lens Light
11	3348110			Lens, Yellow
12	8316433			Pushbutton
13	8524803	W10305985		Switch-WL
14	3400073			Screw, Ground
15	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
16	3949734	W10096320		Cap, End

17 [689559](#)

Nut, Push-In

18 97787

[W10109200](#)

Screw, Baffle Mounting

22 357572

[W10113937](#)

Clip, Grounding

