


Whirlpool CAW2762KQ0 06 - AGITATOR, BASKET AND TUB



Whirlpool Commercial Whirlpool CAW2762KQ0 Washer Parts Parts Diagram 06 - AGITATOR, BASKET AND TUB
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3355758			Cap, Agitator
2	3352284	285630		Plug
3	3363003			Mover, Clothes
4	358237			Screw And Washer
5	3347288			Agitator
6	8316263			Tub Ring And Gasket
7	3359585	3976308		Gasket, Tub Ring
8	21366			Nut, Spanner
9	3951989	W10389329		Clothes Container, Assembly
10	3366877	80040		Dog-Agitator
11	63849			Strain Relief, Power Cord
12	3363661			Bearing, Driven Cam
13	389140			Tub Block, Basket Drive
14	383727			Gasket, Centerpod
15	8524801	353244		Hose, Pressure Switch
16	3363663	285811		Cam-Agitator

20	3946501		Agitator, Assembly
22	3350389	285587	Washer
23	3354733	W10074580	Cap, Barrier
24	3348855	W10072840	Fabric Softener
26	3949550		Washer

