


Whirlpool CAW2762KQ1 01 - TOP AND CABINET PARTS



8316489

2

Whirlpool Commercial Whirlpool CAW2762KQ1 Washer Parts Parts Diagram 01 - TOP AND CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT8524739		Not Available	Literature Parts (Installation Instructions)
"	LIT8533423		Not Available	Literature Parts (Wiring Diagram)
"	LIT8316489		Not Available	Literature Parts (Repair Parts List)
2	8524688			Top
3	3353950			Spacer, Cabinet To Top
4	3351614			Screw, Gearcase Cover Mounting
5	3358500			Panel, Front
6	62780			Clip, Top And Cabinet And Rear Panel
7	358473			Nut, Push-In
8	3400611			Screw And Washer, Lid Switch
9	3953152			Shield, Pressure Switch
10	3353948			Bracket, Lock
11	8054980			Switch, Lid

13	355274	W10119828	Screw, Lid Hinge Mounting
14	21097		Pad, Lid Hinge
15	8524784		Hinge, Lid
16	54583		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	21258		Bearing, Lid Hinge
19	8316257	W10193854W10193854	Lid
20	387371		Lock, Plug Also Available
21	3353812		Locator
22	356908		Bumper, Lid
23	718258	9741232	Screw, 8-18 X 5/8
28	98234		Clip, U-Bend
29	3353993		Screw 10-16 X .690
31	8271956		Splash Shield Assembly
32	356907		Rivet, Plastic
35	3393258	3373329D	Screw
36	3353708	3976380	Panel, Right Hand
37	3353714	3976382	Panel, Left Hand
39	3353949		Pin, Locator
40	18776		Lock, Front Top
43	90406		Cage Nut, 5/16-18

