


# Whirlpool CE2950XSW2 03 - TOP AND CONSOLE

## TOP AND CONSOLE PARTS

For Model: CE2950XSW2



4319347

4

Whirlpool Commercial Whirlpool CE2950XSW2 Dryer Parts Parts Diagram 03 - TOP AND CONSOLE

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">689559</a>			Nut, Push-In
2	688150	<a href="#">697367</a>		Cover
"	689310	<a href="#">697368</a>		Cover
3	<a href="#">3348587</a>			Button, Pushbutton
4	697558	<a href="#">3394075</a>		Switch, Pushbutton
5	<a href="#">385421</a>			Funnel, Coin
6	63795	<a href="#">285653</a>		Endcap
8	3347710	<a href="#">3347718</a>		End Cap
9	<a href="#">3387362</a>			Panel, Control
10	690634	<a href="#">339392</a>		Screen, Lint
11	4319335	<a href="#">3949733</a>		Bracket, Control
12	339230	<a href="#">3978606</a>		Hinge, Lint Lid
"	339229	<a href="#">W10044470</a>		Hinge, RH
13	688983	<a href="#">487240</a>		Screw, For Mtg. Service Capacitor
14	4319339	<a href="#">3387978</a>		Panel, Rear Console
				Screw, End Cap To Bracket

15	355326		Not Available	Screw, End Cap 10 Bracket (4)
16	3390464	<a href="#">3402300</a>		Top
"	3390465	<a href="#">3402301</a>		Top
17	<a href="#">90767</a>			Screw, 8A X 3/8 HeX Washer Head Tapping
18	9424101	<a href="#">965173</a>		Screw, 8 X 3/8 Phlps. Round Hd.
19	<a href="#">3348109</a>			Lens Light
20	3388650		Not Available	Lights, Indicator (240 Volts)
22	343641	<a href="#">681414</a>		Screw, 10AB X 1/2
23	<a href="#">3352295</a>			Guide, Drawer
26	4319336	<a href="#">8527844</a>		Case
"	<a href="#">3419346</a>			Case, Meter (Almond)
27	4319338		Not Available	Bolt, 5/16-24 x 1
28	<a href="#">4319337</a>			Washer, 5/16
29	3347825	<a href="#">3353813</a>		Plate, Mounting
30	64211	<a href="#">388326</a>		Screw, 8-18 X 1.25
32	<a href="#">98460</a>			Nut, Push-In
33	4319340	<a href="#">3351136</a>		Service Door Assembly
"	4319341		Not Available	Door, Service (Almond)
34	<a href="#">689559</a>			Nut, Push-In
35	3348850	<a href="#">3954812</a>		Cushion, Meter Case
36	<a href="#">690853</a>			Wire, Ground
37	340025	<a href="#">687133</a>		Wire
39	<a href="#">339805</a>			Screw, 10-32 X 3/16
40	3387975	<a href="#">279737</a>		Timer
41	<a href="#">3387974</a>			Timing Cam
"	<a href="#">339855</a>			Timing Cam
"	<a href="#">343777</a>			Timing Cam
42	<a href="#">90406</a>			Cage Nut, 5/16-18
44	<a href="#">358409</a>			Screw And Washer
47	<a href="#">387371</a>			Lock, Plug Also Available

