


# Whirlpool CEM2750JQ0 03 - CABINET



6816587

4

Whirlpool [Commercial Whirlpool CEM2750JQ0 Dryer Parts](#) Parts Diagram 03 - CABINET  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3393008	<a href="#">308685</a>		Side Trim )
3	3393258	<a href="#">3373329D</a>		Screw
4	<a href="#">3391846</a>			Clip, Front Panel
5	3394881	<a href="#">279782</a>		Switch-Lid
6	<a href="#">3397659</a>			Block, Terminal
7	3402264	<a href="#">280051</a>		Cabinet
8	3392100	<a href="#">49621</a>		Feet-Leveling
"	<a href="#">279810</a>			Foot-Optional
9	<a href="#">660658</a>			Clamp, Motor Mounting 343481 685441
10	<a href="#">3387374</a>			Spring, Idler
11	<a href="#">3389420</a>			Retainer-Idler 1/4-20 X 1/16
12	697750	<a href="#">W10470674</a>		Dryer Exhaust Kit
13	3388672	<a href="#">279640</a>		Pulley-Idr
14	<a href="#">3387230</a>			Screw, 10-16 X 13/16
15	<a href="#">3394331</a>			Plate Cover
16	<a href="#">3394081</a>			Wire, Broken Belt Switch

17	<a href="#">356674</a>		Cone, Wedge
18	<a href="#">233520</a>		Washer, Thrust
19	<a href="#">297092</a>		Clip
20	<a href="#">690997</a>		Washer, Thrust
21	<a href="#">3389247</a>		Hinge And Pin Assembly
23	<a href="#">3391943</a>		Boot, Foot
25	3393904	Not Available	Cover, Terminal Block
26	<a href="#">3389249</a>		Nut, Inner Door
27	3395656	<a href="#">W10438970</a>	Motor-Drive
28	3389627	<a href="#">W10299847</a>	Pulley-Motor
30	3387610	<a href="#">661570</a>	Belt
31	<a href="#">3390902</a>		Clip, Door Hinge
32	<a href="#">3387118</a>		Bracket, Motor
33	3392186	<a href="#">4159590</a>	Washer
34	<a href="#">279318</a>		Terminal Tinned And Brass Panel
35	<a href="#">279393</a>		Terminal Block Screw Kit
36	3390663	<a href="#">681414</a>	Screw, 10AB X 1/2
39	3388674	<a href="#">W10118756</a>	Idler Bracket
40	<a href="#">3388600</a>		Clip, Lint Duct
41	347207	<a href="#">279347</a>	Switch-Lid
42	<a href="#">98129</a>		Screw, 6-20 X 1 1/16
43	3390814	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
44	<a href="#">3387242</a>		Seal, Front Panel
45	342055	<a href="#">488627</a>	Screw
46	<a href="#">3388229</a>		Retainer, Toe Panel
47	3392563	<a href="#">280083</a>	Door-Rear
48	<a href="#">694091</a>		Trim, Side Right Hand
49	<a href="#">3387872</a>		Door, Front
51	3393081	<a href="#">279722</a>	Panel
52	696144	<a href="#">279570</a>	Latch
53	<a href="#">691581</a>		Lever, Door Switch
55	3390647	<a href="#">488729</a>	Screw
57	<a href="#">3390735</a>		Seal, Door
58	3392538	<a href="#">279570</a>	Latch
59	<a href="#">3398948</a>		Wire, Jumper
60	<a href="#">3389522</a>		Handle, Door
61	697215	<a href="#">3406797</a>	Toe Panel
62	<a href="#">3393657</a>		Restrainer, Belt
64	3391408	<a href="#">8066120</a>	Lever, Door Switch
65	279731	<a href="#">49026</a>	4" - 90° Elbow
66	279818	<a href="#">W10470674</a>	Dryer Exhaust Kit