

14	689559			Nut, Push-In
15	3390646	W10139210		Screw, 8-18 X 5/16
16	3393918	355214		Screw And Washer
17	8281182			Screw, 8-18 X 1 1/4
18	3978608			Panel, Rear
19	3390647	488729		Screw
20	8316640			Lights, Indicator Assembly
21	387402			Hinge
22	8283165			Harness, Main
23	717252			Receptacle, Terminal
24	717253			Receptacle
25	8316433			Pushbutton
26	8316238	279950		Funnel
27	3395683			Receptacle, Multi-Terminal
28	357572	W10113937		Clip, Grounding
29	3391018			Tie Cable
30	353424			Plug, Terminal
31	3406994			Case, Meter
32	3954807			Kit, Vertical 8-Coin Coin Mechanism Parts, May be Ordered From Whirlpool Or The Vend
35	3349065			Bolt, Meter Case Mounting
37	3387975	279737		Timer
40	3387974			Timing Cam
"	339855			Timing Cam
"	343777			Timing Cam
41	3401682			Harness, Timer
43	3351136			Service Door Assembly
44	3954812			Cushion, Meter Case
45	339805			Screw, 10-32 X 3/16
46	3398893	3395559		Wire
47	3394427			Clip-Harness
49	90406			Cage Nut, 5/16-18
51	385421			Funnel, Coin
59	8316526	4396668		Lock-Cam
60	BLANK		Not Available	Slide & Extension
61	8316521	8576635		Bolt
62	8316520			Slide Mechanism Inserts
"	8316264	4396666		Insert
"	8316265	4396667		Insert
63	8316525	4396671		Box
64	BLANK		Not Available	Key, Money Box (When Ordering, Specify Vendor of Money Box Lock)
65	W10128688			Harness, Wiring
66	BLANK		Not Available	Key, Service Door
67	8316523			Extension
68	8316524	4396670		Kit
69	8316532			Installation Instructions Coin Kit
70	3400086			Screw, 10-32 X 3/8