


# Whirlpool CG2951XYG1 04 - 694670 BURNER ASSEMBLY



637274

7

Whirlpool [Commercial Whirlpool CG2951XYG1 Dryer Parts](#) Parts Diagram 04 - 694670 BURNER ASSEMBLY  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	694670	<a href="#">W10492502</a>		Burner-Gas
2	688617	<a href="#">693140</a>		Burner
3	<a href="#">694298</a>			Bracket, Ignitor
4	660991	<a href="#">279311</a>		Ignitor
"	686590	<a href="#">279311</a>		Ignitor
5	686953	<a href="#">3393909</a>		Screw, 8-32 X 7/8
6	343641	<a href="#">681414</a>		Screw, 10AB X 1/2
7	<a href="#">693986</a>			Base, Burner
8	339527	<a href="#">90767</a>		Screw, 8A X 3/8 Hex Washer Head Tapping
9	<a href="#">234826</a>			Orifice, Burner Type 1
"	<a href="#">15775</a>	<a href="#">72017</a>		Paint, Touch-Up
"	15419		Not Available	Orifice, Burner (Type 3)
"	<a href="#">229742</a>			Orifice, Burner
"	<a href="#">234868</a>			Orifice, Burner
10	694054	<a href="#">279923</a>		NAT Gas
11	<a href="#">694421</a>			Screw, Bracket Mounting

12	<a href="#">694538</a>		Bracket, Shunt
13	<a href="#">694540</a>		Coil, 60 Hz
14	<a href="#">694539</a>		Coil, 60 Hz
15	<a href="#">694424</a>		Leak, Limiter
16	<a href="#">694423</a>		Screw, Regulator Adjustment
17	<a href="#">694422</a>		Spring, Regulator
18	694426	<a href="#">3401850</a>	Harness-Gas
19	694510	Not Available	Clip, Harness
20	239822	<a href="#">W10295523</a>	Plug, Pipe
21	233273	Not Available	Pipe, Gas Supply
22	<a href="#">345062</a>		Valve
23	<a href="#">3393767</a>		Pipe, Tail
24	<a href="#">233076</a>		Nut, Compression
25	<a href="#">341029</a>		Clamp, Pipe Door Spring
"	694572	<a href="#">49572A</a>	Conversion Kit To Type L.p.g.f

