


Whirlpool CGD8990XW1 01 - TOP AND CONSOLE PARTS



Whirlpool [Commercial Whirlpool CGD8990XW1 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10184516		Not Available	INSTALLATION INSTRUCTION
"	W10166378		Not Available	TECH SHEET
"	W10469604		Not Available	PARTS LIST
2	W10137411			Top
3	W10337045			Harness, Main
4	W10137459			Console
5	W10135255			Assembly, Membrane Switch And Backer Plate
6	8565237			Bracket, Console
7	W10189075			Washer, Brass
8	3373818			Tab-Grounding
9	W10187276			Seal, Console
10	488234			Screw 8-32 X 1/4
11	3390647	488729		Screw
12	W10137427			Console
13	W10166386			User-Interface Assembly

14	489136		Screw, 3-24 X 1/32
15	W10189313		Inserts
16	W10188087		Ground Wire Assembly
17	W10139046		Nut 6-32
18	8565018		Assembly, Hinge And Pin
19	342055	488627	Screw
20	3347825	3353813	Plate, Mounting
21	98445		Screw, 10-16 X 3/4
22	W10137445		Bracket - Top Panel, Left
23	3390647	488729	Screw
24	W10137444		Bracket - Top Panel, Right
25	W10171132		Meter Case
26	W10267645		Cover, Display
27	W10137457		Screw, 8-32 X 3/64
28	W10131838		Switch, Vault And Service Door
29	W10133508		Bracket, Service Switch
30	W10139210		Screw, 8-18 X 5/16
31	W10211244		Wire, Harness Service Switch
32	3351136		Service Door Assembly
33	W10166307		Harness, Communication
34	W10166308		Harness, Meter Case
35	W10137448		Cushion, Meter Case
36	3349065		Bolt, Meter Case Mounting
37	W10156125		Cam-Lock
38	W10137455		Push Button
39	W10334890		Fascia, Console
40	W10137462		Fascia-Dispenser

the laundry company[®]

the laundry company[®]