


# Whirlpool CGE2991EW1 02 - TOP AND CONSOLE



.981560

3

Whirlpool [Commercial Whirlpool CGE2991EW1 Dryer Parts](#) Parts Diagram 02 - TOP AND CONSOLE  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">357213</a>			Nut, Push-In
2	688150	<a href="#">697367</a>		Cover
3	3949607		Not Available	Bracket, Card Reader
4	<a href="#">3949598</a>			Card Reader
6	<a href="#">3949737</a>			Cap, End
8	<a href="#">3949734</a>	<a href="#">W10096320</a>		Cap, End
9	<a href="#">3402625</a>			Panel, Control
"	<a href="#">3402775</a>			Panel, Control ((French))
10	<a href="#">349639</a>			HAndle And Lint Screen Assembly
11	<a href="#">3402628</a>			Bracket, Control
12	339230	<a href="#">3978606</a>		Hinge, Lint Lid
"	339229	<a href="#">W10044470</a>		Hinge, RH
13	688983	<a href="#">487240</a>		Screw, For Mtg. Service Capacitor
14	386367	<a href="#">8066156</a>		Panel, Rear
15	97787	<a href="#">W10109200</a>		Screw, Baffle Mounting

16	<a href="#">3406410</a>		Top
17	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
22	343641	<a href="#">681414</a>	Screw, 10AB X 1/2
23	<a href="#">3950772</a>		Switch, Membrane
24	<a href="#">717252</a>		Receptacle, Terminal
25	<a href="#">3950773</a>		Backer Plate
26	3950774	<a href="#">3950773</a>	Backer Plate
27	<a href="#">3950775</a>		Backer Plate, Side
28	697812	<a href="#">8566493</a>	Power Relay
30	<a href="#">388326</a>		Screw, 8-18 X 1.25
31	<a href="#">3402741</a>		Harness, Wiring
32	<a href="#">3406192</a>		Nut, Push-In
34	<a href="#">689559</a>		Nut, Push-In
36	<a href="#">690853</a>		Wire, Ground
37	357572	<a href="#">W10113937</a>	Clip, Grounding
38	237446	<a href="#">487596</a>	Washer
39	<a href="#">717253</a>		Receptacle
40	<a href="#">3402740</a>		Board, Control
41	<a href="#">3393909</a>		Screw, 8-32 X 7/8
45	<a href="#">342529</a>		Cap, Terminal (6-Way) (Uses Terminal 94614)
46	<a href="#">3395683</a>		Receptacle, Multi-Terminal
48	<a href="#">3394427</a>		Clip-Harness
49	<a href="#">3402742</a>		Harness, Console
50	<a href="#">3403498</a>		Connector, 3-Position
53	<a href="#">3950779</a>		Bezel, Display
54	<a href="#">3950778</a>		Display, Eletronic
57	<a href="#">693995</a>		Screw, Hex Head
58	<a href="#">717315</a>		Receptacle, 4-Way
60	<a href="#">3403499</a>		Connector, 2-Postion
61	<a href="#">3406407</a>		Vfd Cable

