


Whirlpool CGM2761KQ0 02 - TOP AND CONSOLE, LITERATURE



Whirlpool Commercial Whirlpool CGM2761KQ0 Dryer Parts Parts Diagram 02 - TOP AND CONSOLE, LITERATURE
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT8527795			Literature Parts
"	LIT8316259		Not Available	Literature Parts (Label, Wiring Diagram)
"	LIT8527794		Not Available	Literature Parts (Repair Parts List)
2	357213			Nut, Push-In
3	3361029			Bracket, Control
4	8316634			Panel, Control
5	8316516	W10096340		Cap, End
6	3949734	W10096320		Cap, End
7	97787	W10109200		Screw, Baffle Mounting
8	8316437	W10330137		Switch, Pushbutton
9	8316433			Pushbutton
10	693995			Screw, Hex Head
11	3954665			Top
12	3393918	355214		Screw And Washer
13	3348109			Lens Light

14	689559		Nut, Push-In
15	3390646	W10139210	Screw, 8-18 X 5/16
16	343641	681414	Screw, 10AB X 1/2
17	8316238	279950	Funnel
18	3978608		Panel, Rear
19	3390647	488729	Screw
20	351297		Plug, Harness
21	387402		Hinge
22	8283166		Harness, Main
23	717252		Receptacle, Terminal
24	3954807		Kit, Vertical 8-Coin Coin Mechanism Parts, May be Ordered From Whirlpool Or The Vend
25	385421		Funnel, Coin
26	717315		Receptacle, 4-Way
27	3395683		Receptacle, Multi-Terminal
28	357572	W10113937	Clip, Grounding
29	3391018		Tie Cable
30	3954812		Cushion, Meter Case
31	3406994		Case, Meter
32	3401126		Harness, Timer
33	3936144		Do-It-Yourself Repair Manuals
34	3349065		Bolt, Meter Case Mounting
35	3387975	279737	Timer
36	3387974		Timing Cam
"	339855		Timing Cam
"	343777		Timing Cam
39	8316640		Lights, Indicator Assembly
43	3351136		Service Door Assembly
45	339805		Screw, 10-32 X 3/16
46	3398893	3395559	Wire
47	3394427		Clip-Harness
51	8317340		Cover, Terminal Block
52	3390814	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
53	3401850		Harness-Gas
"	697779		Plug, 3-Way
"	3403498		Connector, 3-Position
"	3403499		Connector, 2-Position
54	3347825	3353813	Plate, Mounting
55	98445		Screw, 10-16 X 3/4
56	90406		Cage Nut, 5/16-18
59	8316526	4396668	Lock-Cam
60	BLANK	Not Available	Slide & Extension
61	8316521	8576635	Bolt
62	8316520		Slide Mechanism Inserts
"	8316264	4396666	Insert
"	8316265	4396667	Insert
63	8316525	4396671	Box
64	BLANK	Not Available	Key, Money Box (When Ordering, Specify Vendor of Money Box Lock)
65	W10128688		Harness, Wiring
66	BLANK	Not Available	Key, Service Door

67

[8316523](#)

Extension

68

8316524

[4396670](#)

Kit

69

[8316532](#)

Installation Instructions Coin
Kit

70

[3400086](#)

Screw, 10-32 X 3/8

