


Whirlpool CGM2941TQ2 02 - TOP AND CONSOLE PARTS



Whirlpool [Commercial Whirlpool CGM2941TQ2 Dryer Parts](#) Parts Diagram 02 - TOP AND CONSOLE PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	357213			Nut, Push-In
2	8283378			Cover, Lint Screen
3	297535	17258		Bumper
4	W10330137			Switch, Pushbutton
5	385421			Funnel, Coin
6	3949737			Cap, End
7	98445			Screw, 10-16 X 3/4
8	3402631			End Cap
9	W10127740			Panel, Control
10	349639			HANDLE AND LINT SCREEN ASSEMBLY
11	3398113	3949733		Bracket, Control
12	3978606			Hinge, Lint Lid
"	3978605	W10044470		Hinge, RH
13	688983	487240		Screw, For Mtg. Service Capacitor
14	3387978			Panel, Rear Console

15	97787	W10109200	Screw, Baffle Mounting
16	8527847		Top
17	8316433		Pushbutton
18	303921	489128	Screw, 8-32 X 27/64
19	693995		Screw, Hex Head
20	3401177		Light, Indicator Assembly
21	3348109		Lens Light
22	3978748	8527844	Case
23	3349065		Bolt, Meter Case Mounting
24	339554	3390631	Screw, 10-16 X 3/8
25	3347825	3353813	Plate, Mounting
26	3954761	279950	Funnel
27	8529862		Harness, Wiring
28	3401126		Harness, Timer
29	3351136		Service Door Assembly
30	689559		Nut, Push-In
31	3954812		Cushion, Meter Case
32	690853		Wire, Ground
33	W10045440		Timer
34	3387974		Timing Cam
"	343777		Timing Cam
35	339805		Screw, 10-32 X 3/16
36	388326		Screw, 8-18 X 1.25
37	3954807		Kit, Vertical 8-Coin Coin Mechanism Parts, May be Ordered From Whirlpool Or The Vend
38	90406		Cage Nut, 5/16-18
39	8316526	4396668	Lock-Cam
40	8318517	8576635	Bolt
41	8316520		Slide Mechanism Inserts
NI	8316264	4396666	Insert
"	8316265	4396667	Insert
42	8316525	4396671	Box
43	N/P	Not Available	KEY (SERVICE DOOR) (WHEN ORDERING SPECIFY VENDOR AND KEY NUMBER)
44	8316523		Extension
45	8316524	4396670	Kit
46	8316532		Installation Instructions Coin Kit
47	3400086		Screw, 10-32 X 3/8