


# Whirlpool CGP2961EW0 04 - 3401771 BURNER ASSEMBLY



4377764

7

Whirlpool [Commercial Whirlpool CGP2961EW0 Dryer Parts](#) Parts Diagram 04 - 3401771 BURNER ASSEMBLY  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3401771	<a href="#">W10492502</a>		Burner-Gas
2	688617	<a href="#">693140</a>		Burner
3	<a href="#">694298</a>			Bracket, Ignitor
4	686590	<a href="#">279311</a>		Ignitor
5	<a href="#">3393909</a>			Screw, 8-32 X 7/8
6	343641	<a href="#">681414</a>		Screw, 10AB X 1/2
7	<a href="#">693986</a>			Base, Burner
8	<a href="#">3387057</a>			Screw, 10-16 X 1/2 Orifice, Burner
9	<a href="#">234826</a>			Orifice, Burner Type 1
"	<a href="#">15775</a>	<a href="#">72017</a>		Paint, Touch-Up
"	15419		Not Available	Orifice, Burner (Type 3)
"	<a href="#">229742</a>			Orifice, Burner
"	<a href="#">234868</a>			Orifice, Burner
10	3401775	<a href="#">279923</a>		NAT Gas
11	<a href="#">694421</a>			Screw, Bracket Mounting
12	<a href="#">694538</a>			Bracket, Shunt

13	<a href="#">694540</a>		Coil, 60 Hz
14	<a href="#">694539</a>		Coil, 60 Hz
15	<a href="#">694424</a>		Leak, Limiter
16	<a href="#">694423</a>		Screw, Regulator Adjustment
17	<a href="#">694422</a>		Spring, Regulator
20	239822	<a href="#">W10295523</a>	Plug, Pipe
21	233273	Not Available	Pipe, Gas Supply
22	3393658	<a href="#">345062</a>	Valve
23	<a href="#">3393767</a>		Pipe, Tail
24	<a href="#">233076</a>		Nut, Compression
25	<a href="#">341029</a>		Clamp, Pipe Door Spring
"	694572	<a href="#">49572A</a>	Conversion Kit To Type L.p.g.f

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>