


# Whirlpool CSP2740KQ3 02 - CONTROL PANEL AND SEPARATOR PARTS



8562520

4

Whirlpool Commercial Whirlpool CSP2740KQ3 Dryer Parts Diagram 02 - CONTROL PANEL AND SEPARATOR PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8283294</a>			Harness, Wire 1a 692998 Receptacle
2	<a href="#">3400000</a>			Screw, 10-24 X 3/8
3	<a href="#">3391018</a>			Tie Cable
4	697776	<a href="#">4331106</a>		Screw, No.10-32 X 7/16
5	98139	<a href="#">303776</a>		Screw
6	<a href="#">3390115</a>			Bracket, Timer
7	3389668	<a href="#">279737</a>		Timer
8	<a href="#">3387974</a>			Timing Cam
"	<a href="#">339855</a>			Timing Cam
"	<a href="#">343777</a>			Timing Cam
"	<a href="#">339854</a>			Timing Cam
"	<a href="#">339853</a>			Timing Cam
9	<a href="#">385421</a>			Funnel, Coin
10	303921	<a href="#">489128</a>		Screw, 8-32 X 27/64
11	3954761	<a href="#">279950</a>		Funnel

12	<a href="#">3979100</a>		Panel, Control
13	8527831	<a href="#">8565384</a>	Insert, Decorative
14	<a href="#">3979325</a>		Lamp, Indicator
"	<a href="#">3979326</a>		Lamp, Indicator
"	<a href="#">3979327</a>		Lamp, Indicator
15	<a href="#">354239</a>		Rivet
16	<a href="#">8283296</a>		Wire Jumper
17	<a href="#">8316437</a>	<a href="#">W10330137</a>	Switch, Pushbutton
18	<a href="#">8316433</a>		Pushbutton
19	<a href="#">3397659</a>		Block, Terminal
20	8539882	<a href="#">3401699</a>	Jumper Wire
21	<a href="#">279318</a>		Terminal Tinned And Brass Panel
22	<a href="#">3400500</a>		Bolt, 3405245 5/16-18 X 3/4
23	<a href="#">3978853</a>		Collar
24	<a href="#">279393</a>		Terminal Block Screw Kit
25	<a href="#">3400029</a>		Nut, Adapter Plate
26	<a href="#">3400094</a>		Screw, 10-32 X 3/8
27	<a href="#">3396795</a>		Cover, Terminal Block
28	<a href="#">3390443</a>		Retainer, Terminal
29	<a href="#">3401699</a>		Jumper Wire
30	96435	<a href="#">356418</a>	Screw
31	<a href="#">8316520</a>		Slide Mechanism Inserts
"	8316264	<a href="#">4396666</a>	Insert
"	8316265	<a href="#">4396667</a>	Insert
32	8316525	<a href="#">4396671</a>	Box
33		Not Available	
34	8316526	<a href="#">4396668</a>	Lock-Cam
35	67001048	<a href="#">67001285</a>	Cover, Light
36	8318517	<a href="#">8576635</a>	Bolt
39	<a href="#">3390424</a>		Extension, Slide
40	<a href="#">3390615</a>		Screw And Cam Bag Assembly
"	B0592401	Not Available	THERMOSTAT
"	C4889201	Not Available	LINE- SUCT

