


Whirlpool CSP2741KQ0 04 - CONTROL PANEL AND SEPARATOR



Whirlpool Commercial Whirlpool CSP2741KQ0 Dryer Parts Parts Diagram 04 - CONTROL PANEL AND SEPARATOR
[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8283295			Harness, Wire
"	3936144			Do-It-Yourself Repair Manuals
2	3400000			Screw, 10-24 X 3/8
3	3391018			Tie Cable
4	697776	4331106		Screw, No.10-32 X 7/16
5	98139	303776		Screw
6	3390115			Bracket, Timer
7	3389668	279737		Timer
8	3387974			Timing Cam
"	343777			Timing Cam
9	385421			Funnel, Coin
10	303921	489128		Screw, 8-32 X 27/64
12	3979100			Panel, Control
13	8527831	8565384		Insert, Decorative
14	3979325			Lamp, Indicator
"	3979326			Lamp, Indicator

"	3979327		Lamp, Indicator
15	354239		Rivet
16	8283296		Wire Jumper
17	8316437	W10330137	Switch, Pushbutton
18	8281149	489128	Screw, 8-32 X 27/64
19	3390189		Strain Relief
20	3401699		Jumper Wire
22	3400500		Bolt, 3405245 5/16-18 X 3/4
23	3978853		Collar
25	96435	356418	Screw
26	98437	595095	Screw, 10-32 X 3/8
27	3396795		Cover, Terminal Block
28	3390443		Retainer, Terminal
29	3401401	3401402	Cord, Power
30	3390424		Extension, Slide
31			Not Available
32			Not Available
33	2170653	2151749	Crisper Cover
34	BLANK		Not Available Security Lock & Cam Assembly
35	BLANK		Not Available Key, Service Door
36	3393262		Bolt, Slide Mechanism

