


Whirlpool CSP2741KQ1 04 - CONTROL PANEL AND SEPARATOR



Whirlpool Commercial Whirlpool CSP2741KQ1 Dryer Parts Parts Diagram 04 - CONTROL PANEL AND SEPARATOR
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8283295			Harness, Wire
2	3400000			Screw, 10-24 X 3/8
3	3391018			Tie Cable
4	697776	4331106		Screw, No.10-32 X 7/16
5	98139	303776		Screw
6	3390115			Bracket, Timer
7	3389668	279737		Timer
8	3387974			Timing Cam
"	339855			Timing Cam
"	343777			Timing Cam
"	339854			Timing Cam
"	339853			Timing Cam
9	385421			Funnel, Coin
10	303921	489128		Screw, 8-32 X 27/64
11	3954761	279950		Funnel
12	3979100			Panel, Control

13	8527831	8565384	Insert, Decorative
14	3979325		Lamp, Indicator
"	3979326		Lamp, Indicator
"	3979327		Lamp, Indicator
15	354239		Rivet
16	8283296		Wire Jumper
17	8316437	W10330137	Switch, Pushbutton
18	8316433		Pushbutton
19	3390189		Strain Relief
20	3401699		Jumper Wire
22	3400500		Bolt, 3405245 5/16-18 X 3/4
23	3978853		Collar
24	3401402		Cord, Power
25	96435	356418	Screw
26	3400094		Screw, 10-32 X 3/8
27	3396795		Cover, Terminal Block
28	3390443		Retainer, Terminal
29	3400086		Screw, 10-32 X 3/8
30	3390424		Extension, Slide
31	8316520		Slide Mechanism Inserts
"	8316264	4396666	Insert
"	8316265	4396667	Insert
32	8316525	4396671	Box
33	BLANK	Not Available	Key (Money Box) (When Ordering, Specify Vendor and Key Number)
34	8316526	4396668	Lock-Cam
35	BLANK	Not Available	Key (Service Door) (When Ordering, Specify Vendor and Key Number)
36	8318517	8576635	Bolt
37	8316523		Extension

