


Whirlpool CSP2741KQ2 07 - 3401797 BURNER ASSEMBLY

3401797 BURNER ASSEMBLY

For Model: CSP2741KQ2
(White)

USE WITH TYPE 1 – NATURAL, TYPE 2 – MIXED,
AND TYPE 4 – LIQUEFIED PROPANE AND BUTANE GASES



8541823

10

Whirlpool [Commercial Whirlpool CSP2741KQ2 Dryer Parts](#) Parts Diagram 07 - 3401797 BURNER ASSEMBLY
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3401797	285904		Burner-Gas
2	688617	693140		Burner
3	694298			Bracket, Ignitor
4	686590	279311		Ignitor
5	3393909			Screw, 8-32 X 7/8
6	343641	681414		Screw, 10AB X 1/2
7	3389871		Not Available	Base, Burner
8	3387057			Screw, 10-16 X 1/2 Orifice, Burner
9	3397656			Orifice, Burner
"	15775	72017		Paint, Touch-Up
10	3401775	279923		NAT Gas
11	694421			Screw, Bracket Mounting
12	694538			Bracket, Shunt
13	694540			Coil, 60 Hz
14	694539			Coil, 60 Hz
15	694424			Leak, Limiter

16	694423		Screw, Regulator Adjustment
17	694422		Spring, Regulator
20	239822	W10295523	Plug, Pipe
21	3387224	Not Available	Pipe, Gas Supply
22	697441		Valve And Union Shut-Off
23	3393767		Pipe, Tail
24	233076		Nut, Compression
25	3387561		Clamp-Pipe
26	3389889		Bracket, Support
"	N/A	Not Available	FOLLOWING PARTS NOT ILLUSTRATED
"	694572	49572A	Conversion Kit To Type L.p.g.f

the laundry company[®]

the laundry company[®]

the laundry company[®]