


# Whirlpool CSP2760HW0 02 - CONTROL PANEL AND SEPARATOR



Whirlpool [Commercial Whirlpool CSP2760HW0 Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL AND SEPARATOR  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">3406275</a>			Harness, Wire
"	<a href="#">692998</a>			Receptacle
2	<a href="#">3400000</a>			Screw, 10-24 X 3/8
3	<a href="#">3391018</a>			Tie Cable
4	697776	<a href="#">4331106</a>		Screw, No.10-32 X 7/16
5	98139	<a href="#">303776</a>		Screw
6	<a href="#">3390115</a>			Bracket, Timer
7	3389668	<a href="#">279737</a>		Timer
8	<a href="#">3387974</a>			Timing Cam
"	<a href="#">343777</a>			Timing Cam
9	<a href="#">3389224</a>			Funnel, Coin
12	3391955		Not Available	Panel, Control
13	3406132		Not Available	Insert, Decorative
14	<a href="#">3349305</a>			Lens, Light
15	<a href="#">354239</a>			Rivet
16	<a href="#">3949703</a>			Knob

17	<a href="#">3387810</a>		Switch, Cycle
18	<a href="#">3388231</a>		Switch, Push- To-Start
19	<a href="#">3397659</a>		Block, Terminal
20	3390895	<a href="#">3393463</a>	Strut
21	340025	<a href="#">687133</a>	Wire
22	<a href="#">3400500</a>		Bolt, 3405245 5/16-18 X 3/4
23	3402754	<a href="#">3978853</a>	Collar
24	<a href="#">688805</a>		Clip, Spring Knob
25	96435	<a href="#">356418</a>	Screw
26	98437	<a href="#">595095</a>	Screw, 10-32 X 3/8
27	<a href="#">3396795</a>		Cover, Terminal Block
28	<a href="#">3390443</a>		Retainer, Terminal
30	<a href="#">W10128688</a>		Harness, Wiring
31		Not Available	
32		Not Available	
33	2170653	<a href="#">2151749</a>	Crisper Cover
34	BLANK	Not Available	Security Lock & Cam Assembly
35	BLANK	Not Available	Key, Service Door
36	DA71-00068A	Not Available	STOPPER-DO
37	<a href="#">279318</a>		Terminal Tinned And Brass Panel
38	<a href="#">279393</a>		Terminal Block Screw Kit
39	<a href="#">3390424</a>		Extension, Slide

